

## D-400S3 with 5.25" Slim Optical Drive

1. Unscrew the drive bay covers



2. Take off the whole HDD cage



- 
3. Mount the 5.25" Slim Drive on the HDD cage



4. Mount the whole HDD cage with the slim optical drive back to the chassis

