



DIY-ON06-80

## Product Details

### *Anti-Noise Cover for 80mm PC Case Fan*

#### **Step 1- Install 80mm Fan face out from inside of the case**



#### **Step 2- Attach DIY-ON06-08 from outside the case to cover 80mm Fan**



**Step 3- unscrew the screws from both side of DIY-ON06-80 and move down the bracket**

