

WA-SF80/96B with iStarUSA Cabinets installation guide

1. 4x cage nuts and screws are needed for the installation.



2. Install 4 cage nuts to the mounting posts



3. Place the tray and secure it with four screws



4. Installation done

