



1. Turn over the WQ-990 cabinet.
2. Use 4 bracket screws to lock one castor.
3. Be careful! There are 2 screws lock with nuts which were put in the groove of cabinet. (The nuts are movable)

PS. Adjust the nuts to aim the hole of castor.