


## How to remove the lid of S-0112-DT and S-0312-DT

The lid is designed to be tight in S-0112-DT and S-0312-DT cases. Follow the steps below to remove the lid for hardware installation.

1. Take off the screw in the rear



2. Hold the case as shown in the picture



3. Press the top cover and push it forward

