


TC-RAIL28-EX34 28" Rail System

Installation guide for EX3M16, EX4M24, and EX4M36-EXP Rackmount Chassis

Maximum Mounting Distance:



The maximum mounting distance is **36.25"**

Minimum Mounting Distance:



The minimum mounting distance is **26.5"**




Outer rails stick out 2.3" from rear end of chassis when rails are mounted with minimum mounting distance 26.5"

Installation Guide:




1. Install and secure inner rails to chassis.




To release inner rails, push the latch and push the inner rail forward



2. Loosen these two nuts (do not remove nuts) in order to adjust rails to desired length when installing rails onto a cabinet/rack.



3. After rails are mounted onto a cabinet/rack, **make sure use tools to tighten the nuts that are loosened in previous step.**



4. Pull the rails (middle rails) all the way out from cabinet and pull one side latch **up** and push the other side latch **down** at the same time when sliding chassis in or releasing chassis from rails.