iStarUSA[®] Group

E1M4 Chassis with RP-RAIL-26-1U Rails Installation

1. Pull the inner slide all the way out until it reaches the end. Then you will see a locking latch at the end point of the inner slide. Press the latch to disconnect the slide.



2. Put the slide right next to the rack mount chassis. You should be able to find screw holes on both sides of chassis. Fasten 6 screws at least to attach the inner slides on to the chassis. (Use M4 Screw)




3. Mount the L shaped bracket onto the outer channel. (use black round head screw)




- 4. Mount the outer channel to the vertical racks.
 - a. Adjust the rail's length to fit the outside of the Rack mounting square.



b. Align the mounting bracket to the inside of the mounting square.



c. Fasten the brackets onto the rack. (Use M5 Screw)





5. Repeat step 4 to mount two rails onto the rack and insert the chassis to the frame.