## Copyright

Copyright © 2006 by iStarUSA, Inc., all right reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, translated into any language, in any form or by an means or otherwise, without the prior written permission of I-Star USA Inc. 11911 Clark St. #C, Arcadia, CA 91006.


iStarUSA Inc. reserves the right to make modification and additions to this product and manual without notice or taking any liability.

#### Disclaimer

iStarUSA Inc. assumes no liability for errors or omissions in this document. Nor dose iStarUSA Inc. make any commitment to update the information contained herein. Pictures in this document are for demonstration purpose only and may not be the same as the actual product.



# **INSTALLATION MANUAL**



## **Package Contents**

Ball bearing sliding rails build from same SECC steel with length of 20, 24, and 26. The rail is built to last and can hold system weight up to 200lbs. Easy maintenance to slide system in and out of cabinet.

#### Package Contents

4 L Brackets 2 Sliding Rail Installation Guide Two Screw Pack

-18 Screws -10 Washers -8 Nuts



x18





L Shape Bracket

Shape Bracket 12"

Operating Altitude: 15,000 feet Temperature: 0-50C (operating) 0-70C (storage) Humidity: 5-95%, non-condensing Safety Standard: FCC/CE

# Specification

Model No. IS-Rail20/24/26 Material 1.2mm SECC Steel


Fit IS-Rail20: 20"~26" Depth Cabinet IS-Rail26: 26"~34" Depth Cabinet

Length IS-Rail20: 20" (Fully extend to 37")


IS-Rail24: 24" (Fully extend to 48") IS-Rail26: 26" (Fully extend to 50")


Weight 5lbs

Cabinet Type Standard / HP




(Pull the center slide all the way out until it reaches the end)







You will see a locking clip at the end point of the center slide. Push it down and unlock the center slide.





Now put the center slide right next to the rackmount chassis. You should be able to find screw holdes on both sides of chassis. Holes are used for mounting the center slide. Later, the center slide will be use for attaching the sliding rail.






Aline front outter rail to the indent of L bracket between Point A & B.





Repeat previous steps to secure sliding rails on both sides.



Reattach inner rail back to center rail