# T-35HD2-SA 3.5" SATA/SAS HDD Cage

# User's Manual




# Specification:

Hot Swap	1x3.5"HDD
Dimension (W x H x D)	4.92 x 1.10 x 7.48 inches
Material	Aluminum
HDD Interface	3.5″ SAS I/II, SATA I/II/III
Weight	0.5 lbs.
Connector	15-pin SATA power and 7-pin Data
Indicators	Power On: green, HD Access: amber blinking

# **Order Information:**

Model Number:	Color:	UPC Code:
T-35HD2-SA	Black	846813034319




### Introduction:

T-35HD2-SA is a mobile rack for use with 3.5" SAS I/II, SATA I/II/III 6.0Gb/s hard drive. The storage capacity of the hard drive is unlimited. LED indicator enables monitor power and hard drive activities. Unique compact design is perfect for OEM/ODM projects.

### Features:


- Aluminum Structure for Best Cooling
- Support 3.5" SAS I/II, SATA I/II/III Hard Drives
- Data Transfer Rate up to 6.0 Gb/s
- Thumb Lock Prevents Theft or Removal During Operation
- Power ON/OFF and Hard Drive Activity LEDs
- Removable Tray Design for Hot-swappable Function
- Optional Tray Color
- Custom Size

## Hardware Information: Front View



A 1: Thumb Lock: keeps the HDDs staying inside the unit and prevents HDDs being taken out while they are running


- A 2: Power LED: Power on, LED indicates green.
- A 3: HDD Access LED: Amber blinking for HDD access.
- A 4: HDD Cage release latch



- B1: 15pin Serial ATA power connector
- B2: 7pin Serial ATA data connector
- B3: HD LED SWTICH (default: left)
- **B4:** External connections

# **HDD Installation:**

- Release the latch and pull out the tray. 1.
- 2. Mount the hard drive on the tray with provided screws.



3. Slide the tray back to the cage.

#### Accessories:

- 1 manual
- several screws



#### iStarUSAcare:




We will help you navigate our website to find the information that you need. Go to www.istarusa.com, and click on live chat bubble above the Search Bar.

Our technicians are standing by to take your questions. Visit http://istarusa.com/support/, and you will receive a technical support ticket to help track your requests from the beginning to the end. Or you can contact us @ 888-989-1189.

FCC and CE Radiation Norm FCC This equipment has been tested and found to comply with limits for Class B digital device pursuant to Part 15 of Federal Communications Commission (FCC) rules. CE This equipment has been tested and found to comply with the limits of the first sequence of t

CC This equipment has been tested and found to comply with the limits of the European Council Directive on the approximation of the law of the member states relating to electromagnetic compatibility (89/336/EEC) according to EN 55022 Class B. FCC and CE Compliance Statement These limits are designed to provide reasonable protection against frequency interference in residential installation. This equipment generates uses and can radiate radio frequency energy, and if not installed or used in accordance with the instructions may class harmful interference to radio communication. However, there is no guarantee that interference will not occur in television reception, which can be determined by turning the equipment of and on. The user is encouraged to try and correct the interference by one or more of the following masures. Recoind or relacing the receiving antenna, Increase the separation between the experiment of the receiver, connect the equipment into an outlet on a circuit different from that to which the receiver is connected to. The Federal Communications Commission warms the user that changes or modifications to the unit not expressly approved by the party responsible for the compliance could void the user's authority to operate the equipment.





Picture C

#### C5: NG

- C6: +5V output
- **C7**: HDD access connection (Note: "+" and "-" position). See it from motherboard manual.